

SPECTRUM PLUS Plasterboard Installation instructions.

For extra consideration over and above the standard installations are the following points:

When commencing installation the aperture or space for the panels should be the stated size of the panel with no obstruction preventing a flush fit.

We advise single module installation of plasterboard models due to expansion.

- Place the panel within the plasterboard void
- Attach the recommended number of wires which should be vertically aligned (please note that the fixing supports can be adjusted along the length of the panels to assist)
- Adjust the wires to achieve the best fit within the ceiling.
- Please note that the panels can only sit flush within a perfectly level ceiling with loose wires.
- Connection to the panel is recommended using flexible hoses of a specification suitable for heating systems.
- Place the panel within the plasterboard void carefully positioning the screw holes depending on frame used, so that they make a secure fixing (timber joists are ideal).
- Then continue final fixing of the panel ensuring a straight flush fit.

