

Plasterboard Installation

For extra consideration over and above the std installations are the following points:

When commencing installation the aperture or space for the panels should be the same size of the panel with no obstruction preventing a flush fit.

We advise single module installation of plasterboard models due to expansion.

Instructions

1. Place the panel within the plasterboard void
2. Attach the recommended number of wires which should be vertically aligned (please note that the fixing supports can be adjusted along the length of the panels to assist)
3. Adjust the wires to achieve the best fit within the ceiling.
4. Please note that the panels can only sit flush with in a perfectly level ceiling with loose wires.
5. Connection to the panel is recommended using flexible hoses of a specification suitable for heating systems.
6. Place the panel within the plasterboard void carefully positioning the screw holes depending on frame used, so that they make a secure fixing (timber joists are ideal).

Then continue final fixing of the panel ensuring a straight flush fit.

